

Spot The Safety Violation: Don't Overload Your Scaffold



What did the employer and workers do wrong to cause this scaffold to collapse'

When built correctly, scaffolds are generally safe for workers to use. But even a well-constructed scaffold can become hazardous if it's overloaded.

This picture from the Health and Safety Executive (HSE) in Great Britain shows what can happen when a scaffold is loaded beyond its maximum load capacity.

A loft conversion company was fined after a worker was injured in this dramatic scaffold collapse. The structure buckled, tipped towards the home and bent in on itself, effectively creating a chute that sent the worker and an array of

materials crashing six metres to the ground below. The 24-year-old worker broke two ribs in the fall, but was fortunate not to have been more seriously injured or even killed.

An HSE investigation into the incident found that the weight of the materials on the scaffold at the time of collapse was between 3-3.5 tonnes—the equivalent of a transit van. This weight was far greater than the scaffold could safely handle and so it gave way.

In addition, the employer should've known the property required a scaffold built to an approved design by a specialist structural engineer. It pleaded guilty and was fined £5,000 (\$9,425 CD).

After the hearing, HSE Inspector Simon Hester said, 'The collapse would not have occurred had the scaffold been designed by a competent specialist to carry loads of 3.5 tonnes with an overhanging cantilever to accommodate the bay window.'

There are two lessons from this British safety incident:

Lesson #1: Ensure Scaffold Is Properly Designed and Constructed

Ensure that any scaffold you use is properly designed and constructed. In some cases, you may need to have the scaffold designed by a professional engineer. You may also need to have the scaffold built or erected by a '[competent](#)' or qualified person.

In terms of the design and construction of scaffolds, the OHS regulations often include general requirements that apply to all types of scaffolds as well as requirements for specific types of scaffolds. The general requirements usually cover areas such as:

- Materials, such as the type of lumber permitted for use

- in wood scaffolds;
- Supports and beams;
- Brackets;
- Planks and platforms;
- Guarding, including use of guardrails and toe boards;
- Ladders; and
- Bracing.

Lesson #2: Ensure Scaffold Can Carry Expected Load

Make sure that the scaffold can carry the load or weight expected to be placed on it. Otherwise, the scaffold could collapse as it did in this incident. (See [this chart](#) for the specific load requirements for scaffolds under each jurisdiction's OHS regulations.)

The basic rule is that a scaffold should be:

- Designed to support and capable of holding at least four times the load that's likely to be on it; and
- Not used for a load that's heavier than 25% of the load for which it's designed.

When calculating the load that's likely to be on a scaffold, consider the weight of all the scaffold's components combined with the following loads that will be or are likely to be imposed on it:

- The actual weight of the workers using it, including their tools, materials and equipment; and
- Wind, wind gusts and other environmental conditions (look what can happen to a scaffold in [windy conditions](#)).

To ensure that workers don't overload a scaffold, they need to know its load limits. A good way to ensure they have this information is to post the load limits on the scaffold itself.

To learn more about ensuring scaffolds are safe for workers to use, read about the [seven steps](#) to take to comply with the OHS

requirements for this equipment.